FUNTEC

FUN Volley Set

PDF Download

8,5 m
Fun Volley Set

Art.-Nr.: 111108

4 260059 370035

FUN Volley Set

AUFBAUANLEITUNG

1



Beide Netzpfosten setzen sich aus je drei Rohren zusammen. Das Rohr mit der schwarzen Kunststoffkappe ist das Oberteil. Schraube die Metallösen in die dafür vorgesehenen Löcher.
Du kannst zwischen zwei Netzhöhen wählen.

Setze nun die gelben Spanngurte zusammen. Achte darauf, dass sich die Schlaufen am Ende der Gurte und nicht am Klemmschloss befinden. Auf diese Weise erhältst du vier Spanngurte. Streife die kleinen Schlaufen über die Erdnägel.

2



3



Die Positionen der Erdnägel werden folgendermaßen festgelegt: Entfalte dazu vollständig das Netz (1). Die Enden bzw. die Schlaufen des oberen Spannseils markieren die Positionen der Netzpfosten (2). Von hier aus werden die Erdnägel jeweils in einem 45°-Winkel in einer Entfernung von ca. 3 m platziert (3). Tipp: Orientiere dich an Abbildung 7 (letzter Schritt).

5



Hänge die <u>großen</u> Schlaufen der Spanngurte und die Schlaufen des Netz-Spannseils an der Spitze der Netzpfosten ein und stelle diese zum Netz hin schräg auf.

Insgesamt erhältst du so vier Verankerungspunkte für die Erdnägel. Diese werden am besten mit einem Gummihammer schräg (<u>vom Pfosten weg</u>) in den Sand geschlagen. Achte darauf, dass du vorher die kleinen Schlaufen der Spanngurte um die Erdnägelköpfe gelegt hast!

4



Spanne alle vier Spanngurte gleichmäßig ab und stelle die Netzpfosten dabei senkrecht. Die roten Leinen werden an den Schraubösen an den Pfosten befestigt. Die gewünschte Netzspannung und genaue Netzhöhe stellst du über die unteren roten Spannleinen ein.

6





Die optimale Netzposition erreichst du durch Nachjustieren der Spanngurte und der unteren Spannleinen. Das Netz sollte genau in der Flucht der Netzpfosten hängen.

TIPPS

- Bevor du dein Set wieder verpackst, befreie insbesondere die Pfosten und Steckverbindungen vom Sand.
- Stecke die Erdnägel zur Aufbewahrung am besten in die Rohre. Dann können sie in der Tasche nicht herausfallen.

EMPFEHLUNGEN

Als Spielfeldmarkierung empfehlen wir dir die Fun Volley Courtline aus 5 mm starker gelber Kordel mit U-förmigen Stahlheringen.



LIFE STARTS NOW
FUNTEC
LET THE GAME BEGIN

FUN Volley Set

SETUP MANUAL

1



Each post is assembled from three pieces. The section with the black cap is the top piece. Insert the metal loops into the holes and secure with the threaded nut provided. You can choose between the two different holes to obtain different net heights.

Assemble the two parts of the yellow straps as shown. Make sure the loops are positioned at the ends of the belt and not near the metal clip lock. Place the small loops of the straps under the disks of the sand anchors.

2



3



To obtain the ideal position for the sand anchors, unfold the net completely (1). The loops at the ends of the top cable mark the places for the posts (2). Drive the anchors into the ground at a distance of approx. 3 m from the post position (3) to form an approx. 45° angle. Also refer to figure no. 7 to get an overview of the correct placement of posts and anchors.

5



Put the larger loops at the other end of the straps over the top end of the posts and put the posts up sloping inwards. Then put the cable loops attached to the top ends of the net over the top of the posts as well.

Use two anchors per post. Make sure to knock the anchors into the ground at a slight angle away from the posts to aid tensioning, ideally using a rubber mallet.

4



Tighten the yellow straps and adjust the position of the post as necessery to get the posts upright. The net must be aligned midway between the poles by adjusting the short red ropes at the top of the net. Adjust the lower ropes to length at the metal loops at the poles.

6





The net tension and net height can be altered to achieve the perfect net by adjusting the tension of the red ropes at the bottom corners of the net.

TIPS

- Wipe the sand off the posts before storing them.
- For transportation store each anchor in a single pole section.

RECOMMENDATION

We recommend the Fun Volley courtline as suitable for this portable Beachvolleyball set. The courtline has a 5 mm rope with metal u-shaped anchors.



	Menge/*Qu.*	Art.-Nr./*ID*
1 Stahl-Pfostenset, 6-teilig, Schraubösen aus Stahl, 2 Bodenplatten aus Kunststoff / *Metal pole set, 6-piece, metal loops, 2 plastic ground plates*	1	111416
2 Erdnägel / *Sand anchors*	4	111408
3 Spanngurte, jeweils 2-teilig / *Tension straps, 2-piece*	4	111407
4 Freizeitnetz, 8,5 m/9,5 m / *Leisure sports net, 8.5 m/9.5 m*	1	111324/111322
5 Packtasche Fun Volley / *Fun Volley bag*	1	111331

4 260059 370035